

Jaguar XJS 2&4 seater 1061

1. Lower roof
2. Remove screws indicated



3. Remove panel (up & forward motion)



4. Remove 17mm seat belt bolt. Remove plate indicated and leave out



5. Fit the wind deflector bracket on the top of the seat belt mount but do not tighten.

6. Refit panel making sure the bracket goes through the seat belt aperture and the seat belt webbing moves freely.

7. Remove panel again to allow you to tighten 17mm bolt and tighten securely. Refit panel using the 3 screws



8. Follow steps 2-7 for the opposite side

9. Connect angled brackets to the wind deflector frame and then fit into place using the thumbscrews



*.Please note different positions for the netting.

