

Important

Six-volt batteries must be kept charged. If allowed to fully discharge, they cannot be successfully recharged. This is not a fault of manufacture and is not covered by warranty.

To maintain a full charge, use BatteryMinder part number 17-3567.

If discharging of the batteries occurs during regular use, ensure the dynamo/generator is functioning correctly and check ancillary components for drain.